

Roku Express 4K+

Quick Start Guide

What's included



Roku Express 4K+ streaming player
3941R/3941RW



Removable adhesive strip



Power adaptor



USB power cable



Remote RC608



Two AAA Duracell® batteries



Premium High Speed HDMI® Cable

Details



HDMI | USB power | Reset

Let's get started




STEP 1: Connect to TV

Connect your streaming player to an HDMI port on the back of your TV with the included HDMI cable. For 4K streaming, you'll need to use an HDMI port that supports HDCP 2.2.

TIP:

For help setting up your device, visit go.roku.com/express4K



STEP 2: Connect to power

For the best streaming experience, use the included USB power cable and power adaptor to connect your streaming player to a wall outlet. Or use the included USB power cable to connect to the USB port on your TV.

NOTE:

See a red light on your streaming player?

That means the USB port on your TV is not providing enough power. Use the included power adaptor instead.



STEP 3: Position streaming player


Place your streaming player near your TV or attach it with the included removable adhesive strip.

DO NOT place your streaming player behind the TV or inside a closed TV cabinet. Doing so may cause overheating.



OPTIONAL

To attach your streaming player to your TV, see the **adhesive strip instructions** on the back page of this guide.




STEP 4: Select input

Use your TV remote to power on your TV and select the input (source) you used to connect your streaming player.



STEP 5: Insert batteries

Slide open the cover on the back of your remote and insert the included Duracell® batteries. Your remote will pair automatically.



STEP 6: Follow the on-screen setup

Follow the instructions on your TV screen. Activate your streaming player by using your computer or smartphone to link to a Roku account.

IMPORTANT:

Roku does not charge for activation support – beware of scams.

Common questions

Why do I need to create a Roku account?

You'll need a Roku account to stream, add channels, easily manage subscriptions, rent movies, and more.

Why do I need to enter a credit card?

Saving a payment method makes it easy to rent or buy movies, subscribe to popular channels, and start free trials in just a click. No charges will be made without your authorization.

What should I do if my streaming player is not connecting to my wireless network?

Double check the network you selected and that you entered your password correctly. If you have other devices connected to this network, your streaming player should connect.

Visit go.roku.com/express4K for more information

Adhesive strip instructions

Use this removable strip if you want to attach your streaming player to your TV. Keep in mind that this strip can only be used once.

To apply adhesive strip



To remove adhesive strip



Need more help?

support.roku.com



Video tutorials



Wireless help

Cut cable. Save money. Stream big.

streamandsave.com



Free TV



Live TV

See what's streaming for free, tips, and more

blog.roku.com

Follow us



ROKU

© 2021 Roku, Inc. All rights reserved. Roku and the Roku logo are the registered trademarks of Roku, Inc. HDMI, the HDMI logo, and High-Definition Multimedia Interface are the trademarks or registered trademarks of HDMI Licensing, LLC. All other logos and trademarks herein not owned by Roku, Inc. are the property of their respective owners.

